

RoClean L211

NSF Certified
High pH RO Membrane Cleaner - Liquid



Performance:

RoClean L211 offers a variety of performance benefits:

- * Compatible with the thinfilm (polyamide) elements of all the major membrane manufacturers.
- * Contains a proprietary blend of buffers, low foaming surfactants and chelants to dissolve organic foulants and disperse colloidal particles.
- * Highly buffered to resist pH changes during the cleaning process.
- * Superior results, especially when compared to generic cleaners.
- * Can be used in conjunction with other applicable cleaners as shown in the Avista cleaner selection guide.
- * Temperature compensated to maintain optimum pH over a wide temperature range.

RoClean L211 is a high pH, low foaming liquid cleaner formulated to remove silt and organic foulants such as colloidal silica, clays, organic color, and bacterial slime from spiral wound thinfilm elements.

RoClean L211 is highly buffered to resist pH changes during the cleaning process and it contains a proprietary blend of buffers, low foaming surfactants and chelants to dissolve organic foulants and disperse colloidal particles.

Use Instructions:

Below is a summary of the RoClean L211 cleaning guidelines. For detailed procedures, please consult the Avista technical bulletin entitled "Cleaning of Spiral Wound Membrane Systems".

1. Fill the cleaning tank to the desired volume with RO permeate or DI water. Heat the solution to 50°C as this will dramatically increase the cleaning efficiency. Add the RoClean L211 to the tank at a rate of approximately 1 gallon per 50 gallons of water. Recycle the solution through the cleaning tank to ensure adequate mixing.

2. Recirculate the cleaning solution through each RO system stage, one at a time, for a minimum of 60 minutes at the flow rate recommended by the membrane manufacturer. If that rate is not known, use the guidelines:

Element Diameter (Inches)	Flowrate per Vessel GPM (LPM)
4	10 (38)
6	23 (87)

3. If the membranes are heavily fouled and the recirculated cleaning solution becomes discolored or turbid, discard as much as 15% of the solution volume. Heavily fouled elements may also benefit from a soak period (up to 8 hours).

4. Monitor the pH of the solution during the cleaning process. If the pH remains in the desired range above 10.5 (at 50°C) and the solution is not turbid, it may be used to clean subsequent stages. In the unlikely event that the pH drops below 10.5, prepare a new batch and repeat steps 1-4.

5. When the clean is completed, rinse the membranes by recirculating RO permeate through each pressure vessel. The system can then be returned to service.

Dilution:

For moderate to severe fouling, RoClean L211 should be mixed at a rate 1 gallon of chemical to 50 gallons of water. For milder fouling, a dilution of 0.5 gallons of chemical to 50 gallons of water may be sufficient.

Packaging:

RoClean L211 is available in 45-pound pails, 500-pound drums and 2500 pound totebins.

Properties:

Appearance:	Colorless to amber colored liquid
Specific Gravity:	1.05 – 1.2
pH:	10.5 to 11.5 at 25°C (2% sol.)

Avista Technologies Inc.
133 North Pacific Street
San Marcos, CA 92069 USA
Phone: 760 744-0536
Fax: 760 744-0619
www.avistatech.com



DRINKING WATER TREATMENT ADDITIVES CLASSIFIED BY NATIONAL SANITATION FOUNDATION.® TO ANSI/NSF 60 ON JULY 1, 2005 AS STANDARD DRINKING WATER TREATMENT CHEMICAL FOR USE OFF-LINE IN REVERSE OSMOSIS SYSTEMS.